


STAND FOR SPLIT DIAL BORE GAGES

- For split type dial bore gages **2421, 2426, 2427 and 2429**
- Maximum working stroke: 50mm
- Accept dial indicator to show measuring depth

Code

2491-250



2491-250

accept dial
indicator to show
measuring depth

